



Thank you for purchasing the Bag-A-Nut Chestnut Harvester. For videos on how to adjust the spacing within your wheels please visit the website below.


<https://baganut.com/chestnutswap>

If you need any additional help, please call the manufacture at 1(904) 641-3934 or email at info@baganut.com

Below you will find the parts to adjust an 18" Collector to your desired spacing. If you are adjusting the spacing on a 36" collector please use double of the suggested parts below.

Required Parts For Spacing Your Machine to Collect Chestnut BURRS only (1 1/2" to 2"):

- 12 qty - Wheels (F0032)
- 22 qty - Ejector Fingers (F0029)
- 11 qty – Spacer Wheel – Black (F0043)
- 2 qty - Large 3/4" Snap-on Spacers (F0027)
- 8 qty – 1/8" Washer (F0013) *(you will need 4qty on each side of the wheel axle between the side bracket and the wheels)*
- 2 qty – 1/16" Washer (F0014) *(you will need 1qty on each side of the wheel axle between the side bracket and the wheels)*



Required Parts For Spacing Your Machine to Collect Chestnut NUT only (5/8" to 1 1/2"):

- 23 qty - Wheels (F0032)
- 22 qty - Ejector Fingers (F0029)
- 2 qty - 3/4" Snap-on Spacers (F0027)
- 1 qty – 1/8" Snap-on Spacer (F0026)
- 6 qty – 1/8" Washer (F0013) *(you will need 3qty on each side of the wheel axle between the side bracket and the wheels)*
- 2 qty – 1/16" Washer (F0014) *(you will need 1qty on each side of the wheel axle between the side bracket and the wheels)*

